



## Snap-On system at Alcon Pharma

## Straightforward system for highest flexibility

In the manufactured articles warehouse of Alcon Pharma GmbH in Freiburg, KBS installed a system, in which the display elements can be removed from and repositioned on the carrier rail.

And this is even possible while the system is in operation, without loosing an active order position.

About 100 A-items with almost identical looking packaging are stored in a continuous flow rack – with receipt-oriented commissioning, that would mean a high risk of errors.

Now Alcon benefits from a minimum error rate and an increased order picking performance.

The display module can be snapped onto the carrier profile (snap-on system) and is adapted by a contact rail.

Only the carrier profile has to be mounted permanently and the display elements can be placed in any position according to requirements.

## Additional features

The multi-colour eye-catching lamp increases the information density – one particular colour can be assigned to each operator.

An acoustic signal emitter confirming acoustically that the OK button has been pressed improves feedback to the operator.



## Advantages at a glance

- Very easy mounting
- Highest flexibility in warehouse division
- Reduction of error rate
- Reliable inventories
- Easy to expand
- Other assembly groups such as scanner interfaces can be used

Your contacts at KBS:

Michael Weiser Phone +49 761 45 255 -50 Michael Wolf Phone +49 761 45 255 -52 Benjamin Feige Phone +49 761 45 255 -53

www.kbs-gmbh.de/en



Burkheimer Str. 10 | D-79111 Freiburg Phone +49 761 45 255 - 0 E-Mail: sales@kbs-gmbh.de